

AMBIUS

Mini Downlight Remote



AMDLREM - Q5071330

PAIRING THE REMOTE

- Wall switch **OFF**.
- Turn the wall switch **ON**.
- Within **5 seconds**, press/hold the Pair button (centre button).
- The light will flash once to confirm successful pairing.
- Pairing is complete.


Repeat these steps for each driver you want to control with the same remote.

INSTRUCTIONS FOR USE

Once paired:

- Press the centre button to turn the lights ON/OFF.
- Press ▲ to increase brightness.
- Press ▼ to decrease brightness.

Operating distance: Up to 10 meters.



If you don't want to use the remote every day

Save Your Preferred Brightness:

- Pair the remote (Follow the above instruction).
- Adjust the light to your preferred brightness.
- Unpair the remote (see below).

The driver remembers the last brightness level, even after power is removed.

When the light is turned ON using the wall switch, it will return to the last saved brightness level.

HOW TO UNPAIR

- With the light ON, press/hold the Pair button (centre button).
- The light will flash once to confirm successful unpaired.

REPLACING A LOST OR DAMAGED REMOTE

If the paired remote is lost or no longer works:


- Wall switch **OFF for 15 seconds**.
- Turn the wall switch **ON**.
- Within **5 seconds**, press the Pair button on your **new remote**.
- The light will flash to confirm successful pairing.

The new remote will automatically replace the previous paired remote.

IMPORTANT!

- Keep the wall switch **ON** when using the remote. One remote can control **multiple paired drivers**.
- If the wall switch is turned **OFF** the remote will remain paired but will only work when wall switch is back **ON**.
- All paired drivers within approx. **10 metres** will respond together.
- If pairing additional drivers in another room, switch **OFF** all other drivers to prevent them pairing again
- A remote can only be replaced when a **new remote** is paired within the first **5 seconds** after power is restored..
- **Multiple lighting groups:** Different remote controls can be used to control different groups of lights throughout your home. Pair each remote with the lights you want it to control. Each driver stores one active remote pairing and can be reassigned at any time by pairing a new remote.
- **All lights when turned off using the light switch could take approx. 2 sec to go off.**
- Replace the battery if the remote operating distance becomes shorter

Dimensions:



The remote USES 1 x 23A battery (INCLUDED)

DISPOSAL

When this remote is no longer used or required, it should be disposed of with household waste. We recommend completing this in the most environmentally friendly way.

Please recycle batteries where facilities exist in your area, check with your local council authority for recycling advice.

PROOF OF PURCHASE

Please retain your purchase receipt for all warranty claims

1 YEAR WARRANTY

Your product is warranted against faults and manufacture defects when used as per instruction for a period of **One year**.

We undertake to replace this product at no charge if found to be defective due to a manufacturing fault during the warranty period. This warranty excludes damage caused by misuse, neglect, shipping accident, incorrect installation, or work carried out by anyone other than a qualified electrical service technician. It also excludes liability for discolouration of paint or plastic, or any user serviceable parts. It does not confer any rights other than those expressly set out above and does not cover any claims for consequential loss or damage.

If your product fails to operate satisfactorily, please return it to the retailer from whom it was purchased to obtain a repair or replacement product. You will need to produce satisfactory evidence of date of purchase. If the product is to be replaced (cannot be repaired) then that replacement will be of the same or similar product or accessory excluding packaging, instruction card etc.

In New Zealand product is covered by the Consumers Guarantee Act (1993). In accordance with the act consumers are advised that: The manufacturer does not undertake that repair facilities and parts are necessarily available for this product.

In Australia, our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

KEEP IN A SAFE PLACE FOR FUTURE REFERENCE

CDB  GROUP

New Zealand

PO Box 100-707

N.S.M.C

Auckland

Phone +64 (0)9 917 4000

Phone 0800 232 633

info@cdb.co.nz

Australia

PO Box 574

South Morang

Victoria, 3752

Phone +61 (0)3 9336 4423

Phone 1300 465 324

info@cdbgoldair.com.au