

PRODUCT & TECHNICAL INFORMATION

Model: AWLSR316LED AWLSR316LEDB

Supply: 220-240V ~ 50Hz

Wattage: 2 x 5W LED GU10

Lumens: 900 (450 per lamp)

Colour Temperature: 3000k

Ingress Protection: IP65

Use: Indoor & Outdoor (Permanent use)

Operating Position: Rigid Vertical surface



SAFETY WARNINGS

- Always read the instructions carefully before installation, failure to do this could result in damage to the product, property or harm to the installer.
- This product must be installed by a licensed electrician in accordance with the Australian / New Zealand Wiring Rules AS/NZS 3000.
- It is recommended that this product be used on a circuit board protected by an Earth Leakage Circuit Breaker or Safety Switch.
- Allow suitable ventilation around the light fitting and do not cover with any material.
- Do not immerse any part of the light fitting in water or any other liquids.
- Regularly inspect the light fitting to ensure that no damage has occurred, if damage is found cease use and replace. Do not attempt to modify this fitting in any way.
- The LED Driver is not replaceable.

INSTALLATION PROCEDURE

1. Ensure power to the circuit is isolated for the duration of the installation and all packaging materials are fully removed.
2. Select the appropriate mounting position and ensure the drain hole is at the lowest position when mounted.
3. Route the supply cable so that the wiring is able to enter the body through the grommet hole at the back of the mounting plate.
4. Remove the mounting plate from the rear of the light by unscrewing the 2 screws on the side.
5. Pierce a hole through the rubber grommet and pass the wiring from the rear of the mounting plate.
6. Use the mounting plate as a template to mark the appropriate mounting holes. Ensure the 2 bolts are installed into the mounting plate before attaching to the surface, they will be needed to attached the lamp body. Once done fit the mounting plate to the surface accordingly.
7. Connect the wiring to the terminal block. **Brown** (Active) is connected to the terminal marked '**A**' or '**L**'. **Blue** (Neutral) is connected to the terminal marked '**N**'. **Green** (Earth) is connected to the screw on the base marked \oplus . This wire should be 10mm longer than the active and neutral conductors so that it would be the last to disengage should a force be applied.
8. Attach the lamp body to the mounting plate and secure using the two screws.
9. Fit the lamp and then fit the top cover to lamp body.
10. Energise the circuit at the mains then turn the individual switch 'ON'.
11. Your light should now operate.

CHANGING LAMPS

Removal

1. Ensure the power is off at the wall switch.
 2. Remove the cover.
 3. Allow the lamp sufficient time to cool before removing (if required).
 4. Unscrew and remove the lamp.
- ❖ Repeat steps 2-4 for models where there are two lamps

Replacement

1. Fit the replacement lamp.
 2. Wipe away any finger marks or dirt.
 3. Refit the cover.
- ❖ Repeat steps 1-3 for models where there are two lamps
4. Turn the wall switch on to test.

CARE AND CLEANING

To clean wipe exterior with a damp cloth. Do not immerse in water.

PROOF OF PURCHASE

Please retain your purchase receipt for all warranty claims.

WARRANTY

Your product is warranted against faults and manufacture when used in normal domestic use for a period of one year.

We undertake to replace this product at no charge if found to be defective due to a manufacturing fault during the warranty period. This warranty excludes damage caused by misuse, neglect, shipping accident, incorrect installation, or work carried out by anyone other than a qualified electrical service technician.

If your product fails to operate satisfactorily, please return it to the retailer from whom it was purchased to obtain a replacement product. You will need to produce satisfactory evidence of date of purchase. If the product is to be replaced (cannot be repaired) then that replacement will be of the same or similar product or accessory excluding packaging, instruction card etc.

In New Zealand product is covered by the Consumers Guarantee Act (1993). In accordance with the act consumers are advised that: The manufacturer does not undertake that repair facilities and parts are necessarily available for this product.

KEEP IN A SAFE PLACE FOR FUTURE REFERENCE

CDB  GROUP

New Zealand

PO Box 100-707
N.S.M.C
Auckland

Phone +64 (0)9 917 4000
Phone 0800 232 633
info@cdb.co.nz

Australia

PO Box 574
South Morang
Victoria, 3752

Phone +61 (0)3 9336 4423
Phone 1300 465 324
info@cdbgoldair.com.au